


LabVIEW



LabVIEW on a Raspberry Pi and LabVIEW NXG Dashboard

By


Wim Tormans




Wim Tormans

- Live in Belgium, work in the Netherlands
- Age: 38 / Married
- Father of 2 (Willeke 9y, Giel 7y)
- Hobbies: Photography, Running, LabVIEW
- Project Architect @ VI Technologies
- Using LabVIEW since 2008
- Using TestStand since 2013
- Certifications:





LabVIEW



▶ LabVIEW™ NXG

Agenda



- Demo 1: blinking LED
- Demo 2: I2C sensor
- Demo 3: Telegram bot << at the booth
- Demo 4: Webservice
- Demo 5: Indoormonitoring (T & RH)

https://github.com/wimvormans/NIDays2019_Demo


Why Did I start this project



- Thermostat in the wrong room
- Thermostatic cranes not broken
- Steffan = always cold
- Bas = always warm
- Jeffrey = always 'configuring' the thermostat and/or cranes



What is the setup?




LabVIEW

▶ LabVIEW™ NXG





- Raspberry Pi_(3B) €38,00
- SHT21 I2C sensor €1,00
- Raspberry Pi case €7,00
- LINX toolkit €0,00
- LabVIEW CE €0,00




Raspberry Pi Installation

- Download Raspbian image from [raspberrypi.org](https://www.raspberrypi.org)
- Flash the image with [Win32DiskImager](#) on uSD
- Boot and [Configure](#) your RPI
- Install LabVIEW2020 CE
- Use the Target Configuration Wizard
- Add a new LINX device to a project




Raspberry Pi IndoorMonitoring

- IndoorData.lvclass (GOOP4 Singleton)
 - Processing of the measurement data
 - Used in main.vi AND in the webservice
- SHT21.lvclass
 - Sensor reading
 - Uses LINX library
- NodeConfiguration.lvclass
 - Configuration file
- IndoorMonitoring Webservice
 - API to access the data
- IndoorMonitoring_Main.vi




IndoorMonitoring WebService

- WebResources:
 - API to the outside world (-> Decoupled UI)
 - VI executes when URL is called
 - VI can have parameters (Ex. Filename)
 - Parameters are in the URL



[http://\"IPAddress\":8002/WebServiceName/VName](http://\)

LabVIEW Web Service Request



LabVIEW NXG WebVI

- LabVIEW NXG (3.1.1) + NXG WebModule
- Web Application Project
- Use HTTP palette to access the webservice
- Host WebVI on a webserver (RPi)



NXG Web Module



Web Application Project

Creates a new Web Application project.



Links


Tools:

- [Win32DiskImager](#) (To write an image to uSD)
- [WinSCP](#) (Copy Files to RPI)
- [VNC Viewer](#) (Open a UI to RPI)
- [Putty](#) (SSH to RPI)



Github repo's:

- [Wim Tormans](#)



DEMO

